

# BGAN LaunchPad 4.0.3 for Intel Mac OS X

Briefing note  
2<sup>nd</sup> June 2010

BGAN LaunchPad version 4.0.3 for Mac is released and available for download now. Go to [www.inmarsat.com/support](http://www.inmarsat.com/support), click on **BGAN**, then on **BGAN LaunchPad**

## In this Release

- Support added for 176 Streaming when using Thrane Explorer 700 or Hughes 9201 BGAN terminals.
- New Icon added in connection panel for 176 Streaming. (Note – Icon only automatically added when **NO** is selected during installing for retaining current user data)

## Fixed In This Release

- Clean up of non critical installation files after installation has completed.

## Recommendations for installation

Inmarsat advises that all customers using Intel MAC OSX install BGAN LaunchPad version 4.0.3 to take advantage of the features of this custom-designed interface to your BGAN terminal.

## Prerequisites

This version of BGAN LaunchPad is a full installer, and so no previous versions of BGAN LaunchPad are required. You must have one of the following supported hardware and operating systems:

Intel MAC hardware running software versions MAC OSX Tiger, MAC OSX Leopard or MAC OSX Snow Leopard

## Installing this version

To install BGAN LaunchPad version 4.0.3

- a. Download the installer from [www.inmarsat.com/support](http://www.inmarsat.com/support), click on **BGAN**, then click on **BGAN LaunchPad**. Follow the on-screen instructions to download the installer to your desktop.
- b. Double-click on the BGAN LaunchPad installer.
- c. Follow the on-screen instructions. Click on **Uninstall** if prompted to uninstall a previous version of BGAN LaunchPad.
- d. During the installation, you will be asked if you want to retain the current user data, for example your BGAN LaunchPad settings from the previous version. Click on **Yes** or **No** as required. (see note below)

The BGAN LaunchPad icon is installed on your desktop. Double-click on the icon to open BGAN LaunchPad.

*Note:*

*If **YES** is selected in step d then the new icon for 176 streaming will not automatically appear in the Data Connection Control panel as your previous settings will remain as request. For the new icon to be available please follow these manual steps:*

1. With LaunchPad version 4.0.3 running, select "LaunchPad data tab options" from the "BGAN Services" menu options
2. In the connections tab windows select "Add New Connection"
3. Select "Standard IP or Streaming IP or BGAN X-Stream IP Data connection" radio button and click "OK"
4. In the Icon label box, type "176"
5. Select the "Streaming" radio button
6. Select 176K for the Desired Rate (Minimum rate should be greyed out). Leave the APN settings to use the default and click "Apply"
7. The following message should appear "New primary connection icon created", click "OK" and click "Close" to close the connection type window as you do not need to create another icon.
8. The new Icon has been created but will be positioned last, scroll to the end and click the new "176" icon, then using the "move left" and "move right" buttons move the new icon to your desired position, recommend after 128 and before 256. Click "Close" to close the "connections tab" window
9. The new "176" Streaming icon should now be visible in the Data Connection Panel when using the Thrane Explorer 700 or Hughes 9201



## Using TCP Accelerator

TCP Accelerator version 17.5 for Intel MAC is released and available for download now. To download, either:

- Go to [www.inmarsat.com/support](http://www.inmarsat.com/support), click on **BGAN**, then on **TCP Accelerator**. Follow the on-screen instructions.
- Go to the **Update** menu in BGAN LaunchPad.

**Note:** TCP Accelerator is not included as part of BGAN LaunchPad. You must install it separately to take advantage of the improved performance that TCP Accelerator provides over BGAN.

## Further documentation

Refer to the following guides for help in using BGAN LaunchPad.

- For general information on using BGAN LaunchPad, click on **Help** in BGAN LaunchPad.

For information on using features that are specific to each terminal, or for guidance on using certain technologies or third-party products over BGAN, go to the Inmarsat website, at [www.inmarsat.com/support](http://www.inmarsat.com/support). Click on **User guides**.

## [inmarsat.com/bgan](http://inmarsat.com/bgan)

Whilst the above information has been prepared by Inmarsat in good faith, and all reasonable efforts have been made to ensure its accuracy, Inmarsat makes no warranty or representation as to the accuracy, completeness or fitness for purpose or use of the information. Inmarsat shall not be liable for any loss or damage of any kind, including indirect or consequential loss, arising from use of the information and all warranties and conditions, whether express or implied by statute, common law or otherwise, are hereby excluded to the extent permitted by English law. NMARSAT is a trademark of the International Mobile Satellite Organisation. Inmarsat LOGO is a trademark of Inmarsat (IP) Company Limited. Both trademarks are licensed to Inmarsat Global Limited. © Inmarsat Global Limited 2008. All rights reserved.